Important Instructions:

- Switch off the appliances, and plug out before Disassembly
- Take care PBAs components to avoid any electrostatic charge or physical damage during replacement

1 Switch off the appliances first Plug-out the Main plug



2 Remove all screw and open the back cover to open the panel



- Remove the Display panel connector from the main PBA
- 4 Open all 3 screws of coil





- 5 Open all 4 screws and remove the connectors
- 6 Replace the Main PBA

